

TO CLEAN CARPET:

1. PREPARE THE MACHINE

Make sure the switch is in the "OFF" position and all hoses are connected. Using only approved cleaning solution, mix according to the bottle instructions and pour in the correct side of the bucket. Use the fill level label to fill with the correct amount of solution. To reduce foaming, pour 2 ounces of defoamer into the recovery bladder. Place bucket onto machine and close lid.

2. TO CLEAN

For 411TR models, turn the solution control valve on the side of the machine to "CARPET". Turn the black rocker switch to the "PUMP" position and turn the Brush and Vacuum switches to the "ON" position. While pushing the "ACTIVATE" switch, pull the machine as you step backwards. Release the "ACTIVATE" switch 6 inches before ending a stroke. Repeat cleaning stroke with 3" overlaps. Continue until cleaning solution is consumed. Empty and rinse bucket. Repeat steps 1 and 2

3. CHECK BUCKET LID

If excessive foam appears in the lid, add 2 ounces of defoamer or empty and rinse the bucket. Repeat steps 1 and 2.

4. CLEAN MACHINE BEFORE RETURNING

Clean the lid filter screen and rinse out bucket. Wipe all surfaces including the bottom of machine. Remove carpet lint and strings from brush and vacuum nozzle.

TO CLEAN UPHOLSTERY:

Cleaning upholstery with success requires a good knowledge of the type of fabric to be worked on. Look for the cleaning label sewn on the underside of the furniture for the recommended method of cleaning the fabric. If it calls for dry cleaning, do not attempt to clean with the wet extraction method. Otherwise, damage to the fabric could occur. Extraction works on most synthetic fibers. Before proceeding, test fabric for colorfastness. Pour a small amount of cleaning solution on the fabric in an inconspicuous spot. Rub the area with a white terry towel. If no color comes off the towel, the fabric should be safe to clean. If color transfers, do not continue.

1. PREPARE THE MACHINE

Complete Step 1 under Carpet Cleaning Instructions using approved Upholstery Cleaning Solution. Disconnect the vacuum hose with black hose cuff from the lid and disconnect the solution hose from the back of the machine. Replace them with the upholstery hoses.

2. TO CLEAN

For 411TR models, turn the solution control valve located on the side of the machine to "CARPET". Turn the black rocker switch to the "UPHOLSTERY" position. Turn the Vacuum switch to the "ON" position. Depress upholstery tool trigger while pulling tool across upholstery surface with overlapping strokes. To speed drying go over the upholstery without depressing the trigger. Continue cleaning until cleaning solution is consumed. Empty and rinse bucket. Repeat Step 1 and 2.

3. CHECK BUCKET LID

See Step 3 under "To Clean Carpet."

4. CLEAN MACHINE BEFORE RETURNING

See Step 4 under "To Clean Carpet."