

Wheel pin slot must be placed in lower hole while towing the conveyor.

While conveyor is in use, wheel pin must be placed in top hole or removed.

The towing coupler must be removed while using the conveyor.



055-0928

Conveyor Specifications

24' Long, 10" Wide belt w 2" buckets

Belt speed - 160 feet per minute

Load Capacity 500 lbs.

1.5 HP electric motor

Wheel base = 45"

Unit weighs 650 lbs.

Plug the machine into a location that has 15 amp minimum output. Once plugged in, press the green button to start the machine, and then press the red button to stop the machine.