

Definitions: Safety Alert Symbols and Words

This instruction manual uses the following safety alert symbols and words to alert you to hazardous situations and your risk of personal injury or property damage.

! DANGER: Indicates an imminently hazardous situation which, if not avoided, **will** result in **death or serious injury**.


! WARNING: Indicates a potentially hazardous situation which, if not avoided, **could** result in **death or serious injury**.

! CAUTION: Indicates a potentially hazardous situation which, if not avoided, **may** result in **minor or moderate injury**.

! (Used without word) Indicates a safety related message.

NOTICE: Indicates a practice **not related to personal injury** which, if not avoided, **may** result in **property damage**.

Fig. A



- 1 On/Off switch
- 2 Motor arm assembly
- 3 Plunge handle
- 4 Head lock knob
- 5 Cutting wheel cover

- 6 Cutting wheel
- 7 Rubber shroud
- 8 Small rear water attachment
- 9 Large rear water attachment

- 12 Small cutting cart water attachment
- 13 Large cutting cart water attachment
- 14 Cutting cart side attachment
- 15 Water pan
- 16 Saw frame assembly
- 17 Water nozzles
- 18 Cutting cart stop knob
- 19 Edge guide
- 20 Cutting wheel cover knob



WARNING: Read all safety warnings and all instructions. Failure to follow the warnings and instructions may result in electric shock, fire and/or serious injury.



WARNING: To reduce the risk of injury, read the instruction manual.

If you have any questions or comments about this or any product, call DeWALT toll free at: (1-800-433-9258).