

INSTRUCTIONS

0531

1. **INTENDED USAGE:** Knee Kickers should be used for light carpet stretching, since hard kicking can be injurious to the user. Use a power stretcher in cases requiring more than light kicking.
2. **LENGTH ADJUSTMENT:** A press of the trigger allows the choice of 9 length adjustments from 18½" to 23".
3. **PIN PENETRATION:** The pin adjustment dial gives a visual reference showing pin depth. Set the depth to the approximate carpet thickness. In use, the long pins should reach through the pile into the carpet backing, but not through the backing.
4. **BUMPER PAD ROTATION:** The bumper is seamless and is foam-filled. The pad can be turned for an even distribution of wear.