

READ AND SAVE THESE INSTRUCTIONS



Illustration of Touchpad

How to Use the Touchpad Control Keys

The Touchpad on DrizAir dehumidifiers has one display and four keys. The normal display messages are:

DEHUMIDIFIER OFF	CMPRSR DELAY
DEHUMIDIFIER ON	PUMP PURGING
TOTAL HRS	DEFROST ON
JOB HRS	GET SERVICE ERO1

When you first plug in the unit, the touchpad display will cycle continuously through three messages: DEHUMIDIFIER OFF, TOTAL HOURS, and JOB HOURS.



ON-OFF. Press the ON-OFF key to turn the unit on or off. When turning the machine on, usually the display reads CMPRSR DELAY and performs a numeral count down from a maximum of 60 seconds to 0. The compressor delay gives the machine time to warm up (when needed). If you don't see a compressor delay countdown, the machine is ready to go. Once the unit completes the CMPRSR DELAY, the display reads DEHUMIDIFIER ON, and continues to cycle between TOTAL HOURS, JOB HOURS and DEHUMIDIFIER ON.

Press the ON-OFF key again to turn the unit off. The display will read DEHUMIDIFIER OFF.



DISPLAY. Press the DISPLAY key to stop the display at DEHUMIDIFIER ON or OFF, TOTAL HOURS, or JOB HOURS as it cycles. Press DISPLAY again to re-start the display cycle.

How to change the language display

CAUTION

While in the change-language mode, pressing other keys can change the programming of the machine. Do NOT press other keys you're not instructed to press.

Use the DISPLAY key to change the display language. Follow these steps:

1. Start with the unit unplugged.
2. While holding down the DISPLAY key, plug the unit in. The display reads ENGLISH.
3. To change to FRANCAIS, DEUTSCH, or ESPANOL, press the DISPLAY key or the CLEAR key.
4. When the desired language is shown in the display, unplug the unit, and the language is set.



CLEAR. Press the CLEAR key to reset the JOB HOURS:

1. As the display cycles between DEHUMIDIFIER ON, JOB HOURS, OR TOTAL HOURS, press the DISPLAY key when JOB HOURS appears on the screen. That will make the display read JOB HOURS steadily.
2. Then press the CLEAR key to re-set the numerals to 00000.
3. Press DISPLAY again to re-start the display cycle.

NOTE: the TOTAL HOURS reading cannot be re-set.

40-615
50

READ AND SAVE THESE INSTRUCTIONS

WARNING



ELECTRIC SHOCK HAZARD

Unplug unit before performing any maintenance.

Never use a water hose or pressure washer to clean coils; water could enter the electrical compartment causing a shock hazard.

Follow cleaning instructions in manual.



PURGE. Press the PURGE key to empty water from the pump reservoir. During normal operation, the pump purges automatically every six minutes, or whenever the reservoir is full. The display will read PUMP PURGING with a numeral countdown.

To purge the pump manually:

- 1) Turn the power off using the OFF key, and let the unit sit plugged in for about 10 minutes. This allows water to drip from the coils.
- 2) Press PURGE to remove residual water.

Other displays

Defrost cycle

During normal operation, the temperature sensor detects frost forming on the coils, causing a defrost cycle to start. The display will read DEFROST ON. Dehumidification stops during the defrost cycle. When the unit completes the cycle, the display returns to DEHUMIDIFIER ON.

Error messages

When the display menu shows the error message "GET SERVICE," followed by "ER01" or another numeral, follow these steps:

1. Unplug the unit and then plug it back in. This may re-set the electronics.
2. If that does not fix the problem, try the solution (if one is listed) in the "Error Message Table" to the left.
3. If that does not fix the problem, contact the Dri-Eaz Service Department at 888-867-3235.

Error Message Table

ER 1,2,3,5, 6	Problem with electronic control panel. Contact Dri-Eaz Service at 888-867-3235.
ER 4	Check the temperature or sensor cable, contact Service for instructions 888-867-3235.
ER 8	Check the touchpad key. Press and release each key several times.
ER 9	Check for obstructions or kinks in the drain hose.

Maintenance

MAINTENANCE INTERVALS



WARNING



ELECTRIC SHOCK HAZARD

Unplug any DrizAir dehumidifier before performing maintenance.

Before Each Use

- Inspect the electrical cord for damage. Look for fraying, cuts, etc. Do not use the unit if you find any. Call Dri-Eaz for the nearest Service Center 888-867-3235.
- Inspect filter. Look for accumulated dust and dirt that would restrict airflow through the filter into the unit. If any is visible, vacuum out the debris. **Do not wash the filter**, as it will reduce the effectiveness of the electrostatic material.

IMPORTANT: Replace the filter whenever

- It has been vacuumed clean 3 times
- It has been used on a mold remediation job

Monthly

Remove housing, in order to locate the coils, catch basin, float shaft, and drain hose.